



Consist of:

Anemometer: MAX40+D (modified with internal calibration electronics)

Wind vane: DIR 21+

Bracket with mounting box, 12 meter cable (can be extended using extension cable and cable connector)

2 stainless steel u bolts for mast up to 40 mm

Inside box connections and 3.6 V AA lithium battery (for appr 10 years of operation)

1. Connections inside box:

4 wire cable with RJ connector:  
(direct to plug in ISS/or transmitter)

Windvane:

Green.....◇.....Black.....min pole battery.....Black...◇.....Red  
Brown.....◇.....Yellow  
White.....◇.....Green

Anemometer: type MAX40+D

Red.....◇.....Red.....plus pole battery  
Black.....◇.....Black  
Shield.....◇.....Black.....min pole battery

◇ is crimp splice connector

Connections are be made in waterproof cabinet using splice connectors.  
If sensors need to be replaced use new splice connectors.

2. Adjustment Vantage PRO console (in setup mode):

Select SMALL windcups!

Succes!

[www.ekopower.nl](http://www.ekopower.nl)